

Manuale d'uso - Effizienz Energetica / User Manual - Energy Efficiency / Manuel de l'utilisateur - L'efficacité énergétique / Handbuch - Energieeffizienz / Handboek - Energie-efficiëntie Manual - Eficiencia Energética / Manual - Eficiência Energética / Manuell - Energieeffektivitet / Manuell - Energieeffektivitet / Manuaalinen - Energy Efficiency / Manual – Energieeffektivitet Руководство - Энергоэффективность / Käsiiraamat - Energiatõhususe / Rokasgrāmata - Energieeffektivitātes

Table with 14 columns: Model (S, M), Manufacturer (FABER), Power (325.0541.070 P1665), and various efficiency metrics (AEchood, EEC, FDEhood, FDEC, LEhood, LEC, GFEhood, GFEC, Qmin, Qmax, Qboost, SPEmin, SPEmax, SPEboost, P0, Ps, F, EELhood, Qbep, Pbep, Qmax, Wbep, WL, Emiddle, Lwa, WL, Emiddle, Lwa, CONSIGLI PER IL RISPARMIO ENERGETICO, CONSIGLI POUR L'ECONOMIE ENERGÉTIQUE, CONSELHS PARA EL AHORRO DE ENERGÍA, CONSELHOS PARA POPULAR ENERGIA, RAD FOR ENERGIBESPARING, RAD FOR ENERGIBESPARING, RAD FOR ENERGIBESPARING, ENERGIASAASTUNOJUVA, ENERGIASAASTUNOJUVA, ENERGIASAASTUNOJUVA, ENERGIASAASTUNOJUVA, ENERGIASAASTUNOJUVA, ENERGIASAASTUNOJUVA). Rows include technical specifications and safety instructions in multiple languages.

